



SEATING



www.mce.md.gov



Bel Air Jr.

Also available in Quick Ship



BEL AIR JR. CHAIR FEATURES



Maximum Support

For maximum support, sit as far back in the seat as is comfortable and lean against the backrest.

Arm Height Adjustment

To adjust the arm height, push the button in and then raise or lower the arm.

Seat Height Adjustment

Seat height is adjusted with a pneumatic cylinder. To lower height while seated, lift the lever at the right front of the seat. To raise the height, remove your weight from the seat while lifting the lever.

Back Angle Adjustment

To lock the back at a given angle, first recline to the desired position and then push lever back to lock. To resume free float, push lever forward.

Lumbar Adjustment

For vertical adjustment, grasp lumbar pad from behind chair with both hands. Raise or lower to desired position. For horizontal adjustment, turn knob clockwise to adjust inward or counter clockwise to adjust outward.



Tilt Tension Adjustment

Adjust by using the knob directly under the front of the seat. To increase the tension of the tilt, turn the dial clockwise. To decrease tension, turn the dial counter-clockwise.



BEL AIR JR.

Slightly smaller than the original Bel Air chair, this product offers comfort and functionality at an affordable cost. The Bel Air Jr. provides a breathable mesh back that conforms to your back and allows for air ventilation and natural cooling. Paired with a well cushioned seat, it offers the ultimate in comfort. Additional features include an easy-to-use lumbar adjustment, height adjustable arms and contoured polyurethane pads. Subtle and sleek, the Bel Air Jr. is satisfying seating at an equally satisfying price.

Dimensions

Overall	22 3/4"W x 25"D
Back	20"W x 20"H
Seat	20 1/2"W x 19 1/2"D
Seat Ht Range	17" - 22"

Item No. 122013	No arms	\$274.00
Item No. 122014	With arms*	\$325.00

FABRIC & FRAME COLOR: BLACK



MARYLAND CORRECTIONAL ENTERPRISES

For more information:
Contact Customer Service 410-540-5454
www.mce.md.gov